

HOW TO ADJUST YOUR RH LOGIC 400/300

PERFORMANCE • DESIGNED FOR HUMAN

1



HEIGHT OF THE CHAIR

2



BACKREST ANGLE

3



SEAT DEPTH

4



BACKREST HEIGHT

5



UNLOCK THE DYNAMIC
TILT

6



TILT RESISTANCE

7



LUMBAR PUMP

8



ARMREST HEIGHT

9



NECKREST



FLOKK.COM/RH

